

## Wrap Dispenser

*Easily wrap your carpet and vinyl with the Accu-Cut wrap dispenser. Simply place your stretch wrap, plastic or paper on the dispenser then activate the roll-up cradle by engaging the switch on the wrap dispenser. Improve your roll processing efficiency by adding an Accu-Cut wrap dispenser to your cutting machine.*



## Core Dispenser

*Quickly and simply drops a cardboard tube into the roll-up cradle. Increase your cut order efficiency by adding a pneumatically powered core dispenser to your cutting machine.*

